



T E L A F I N A

MAXWELL FABRICS & TELAFINA
TOLL FREE TEL 1 800 663 1159
TOLL FREE FAX 1 800 663 6744
maxwellfabrics.com

**** DO NOT CUT OR INSTALL UNTIL YOU HAVE READ THESE INSTRUCTIONS ****

GRASSCLOTH HANGING INSTRUCTIONS AND CARE:

Thank you for selecting our exquisite, handmade wallcoverings. To achieve the best outcome, we recommend that a professional wallcovering installer apply these products.

The grasscloth material is crafted from natural fibers, which may lead to slight variations in both color and texture. This characteristic is part of the charm of grasscloth, distinguishing it from nonwoven wallpaper options.

As expected, there may be differences between drops, and seams will be noticeable. However, by following our installation guidelines, you can achieve an even more polished result.

Set up

- Verify that you have the correct product and sufficient wallcovering to complete your installation.
- Carefully inspect the wallcovering for any defects or damage before proceeding. Claims will not be accepted after installation or after 30 days from the invoice date.
- For optimal results, measure twice before cutting your drops. Consider arranging the drops from light to dark for consistent shading, or mix them up to evenly distribute any variations throughout the room.
- Lightly dampen the back of the wallcovering with clean water using a sponge or spray bottle. Allow it to soak for about four minutes to make the paper flexible. **DO NOT OVER-SOAK.** Only work with one drop at a time.

ANY CLAIMS MUST BE SUBMITTED WITHIN 30 DAYS FROM THE INVOICE DATE. Claims are strictly limited to the replacement of defective wallpaper. Labor claims will not be accepted under any circumstances.

Pasting and Hanging

- Avoid getting paste on the surface of the wall.
- Apply a high-quality, pre-mixed adhesive to the wall. Hang three drops, then step back to ensure you're satisfied with the placement before continuing.
- If any defects are noticed at this stage (or during any point in the installation), do not proceed with hanging additional material until Maxwell has been notified.

Use a metal edge and a sharp blade to trim any excess at the top and bottom, ensuring to replace the blade regularly for clean cuts.

- When hanging the first length, use a plumb line to ensure wallpaper is straight. Then, smooth the paper onto the wall with a paperhanger's brush, working from the center out to the edges to eliminate any air bubbles.



MAXWELL FABRICS & TELAFINA

TOLL FREE TEL 1 800 663 1159

TOLL FREE FAX 1 800 663 6744

maxwellfabrics.com

Caring and Cleaning

Grasscloth wallpaper is water-resistant but not washable. It is best to lightly dust or vacuum it to maintain its appearance. Avoid using cleaning products, as moisture can damage the wallpaper. Do not use brushes on the surface, as the pressure can harm the grass fibers. To remove stains, gently rub the foam of mild dishwashing liquid with a soft, white cloth. Refrain from using any harsh cleaning agents